



As you can clearly see in these drawings, the bottom part consists of a frame within a frame. This way we can use standard wood dimensions, whilst it also helps to keep the overall height of the box within the expected aspect ratio.

The PCB should be fitted on top of the inner frame, whilst the Steckerbrett will go on the front of the inner frame. You may want to use small hinges to fix the Klappe (front panel lid) and the top cover. A suitable lock may be added to complete your design.

In order to fit both PCBs nicely, you may need to add extra supporting wooden strips and wedges. Please refer to the website for some detailed images.

If you've managed to design and build your own case, please let us know. We would very much like to learn about other designs and present any ideas on our website. Our e-mail address can be found on page 2.

