



- | | |
|-----------------------------------|---------------------------------|
| 43 Glühlampen | 47 Tastkontakte (Ruhekontakte) |
| 44 Chiffre. Walzen-Kontakte | 48 Lampenkontakte |
| 45 Kurzschlußbleche | 49 Federnde Lampengegenkontakte |
| 46 Tastkontakte (Arbeitskontakte) | 50 Buchsen im Steckerbrett |

The above image was taken from the original Enigma manual and shows a simplified circuit diagram of the machine. The legend is given in the original German as well as in a suitable English translation.

- | | |
|-----------------------------------|----------------------------|
| 43 Glühlampen | Lamps |
| 44 Chiffre. Walzen-Kontakte | Coding wheel contacts |
| 45 Kurzschlußbleche | Contact strip |
| 46 Tastkontakte (Arbeitskontakte) | Key contact (closed) |
| 47 Tastkontakte (Ruhekontakte) | Key contact (open) |
| 48 Lampenkontakte | Lamp contact |
| 49 Federnde Lampengegenkontakte | Spring loaded contacts |
| 50 Buchsen im Steckerbrett | Sockets on the patch panel |